



INTEGRATED TRIM CONTROL

COMPLETE CONTROL™ of your sterndrive
or outboard engine trim



- **CONVENIENTLY** change the running position of the engine drive unit from the control head handle or keypad
- **CONTROL SIGNALS FOR TRIM** commands are sent over existing control system communication cables — no additional wires to run
- **COMPATIBLE** with Glendinning's Complete Control™ - Smart Actuator II systems
- **FOR USE WITH** stern drive & outboard engine applications

“Relax . . . we’re on board!”

FEATURES




Built-in control handle switch makes on-the-fly adjustments to trim of both engines!

Keypad buttons allow you to trim one engine at a time!



- Neutral gear indicator lights — tells you when the transmission is in neutral.
- Dedicated Trim / Tilt buttons move engine drive unit with a simple press!
- Operating mode buttons for quick access to all operations (ACTIVE, WARM, & SYNC)
- Utilizes existing control system communication cables — no additional wires to run!
- Compatible with Glendinning's COMPLETE CONTROL™ - Smart Actuator II™ electronic engine control systems.



740 Century Circle
Conway, SC 29526

Phone: (843) 399-6146
Fax: (843) 399-5005

www.glendinningprods.com
EECF-3 10/06